

MG6K 固件说明

1. 请使用 U 盘拷贝固件到根目录，U 盘需要 FAT32 格式，且根目录下同时只能存在一个固件（bin 文件）。
2. 将 U 盘接入灯具 u 盘接口后，打开灯具电源，等待升级进度条完成。
3. 版本号查看方法：进入菜单里灯具信息查看。
4. 版本说明：

版本	更新内容	日期
V1.11	优化附件控制	20251215
V1.09	新增电动附件的控制功能，且优化附件适配	20250908
V1.04	优化细节问题	20250618
V1.01	优化附件识别.	20250430

注：详细规格请在官网（www.godox.com.cn）下载最新说明书。

1. Please use a USB flash drive to copy the firmware to the root directory and the U disk needs to be in FAT32 format. At the same time, only one firmware (bin format) can exist in the root directory.
2. Insert the USB flash drive into the USB port of the light, and turn on the light. Wait for the upgrade progress bar to complete.
3. To check the version number: Go to the menu and check the INFO.
4. Version Instructions:

Version	What's new	Date
V1.11	Optimized accessory control	2025-12-15
V1.09	New function for motorized accessories control and optimized accessory compatibility	2025-09-08
V1.04	Optimized detail issues	2025-06-18
V1.01	Optimized accessories recognition	2025-04-30

Note: For more details, please download the newest instruction manual on the official website: www.godox.com.